



Polígono Ind. Bayas c/ Suzana Parc.134

09200 MIRANDA de EBRO (Burgos)

☎ (+34) 947.34.78.20 ; 📠 (+34) 947.32.01.19

✉ macrel@macrel.es; www.alba.es

PLATAFORMA DE TRANSPORTE POR CREMALLERA

Rack and pinion transport platform

PT-450

MANUAL DEL OPERADOR


/USER'S MANUAL

- INSTRUCCIONES DE MONTAJE,
USO Y MANTENIMIENTO

/ Installation, use and maintenance instructions

- LISTAS DE REPUESTOS

/ Spare parts list



Nº máquina /Nb: _____

Modelo /Model: _____

Año de fab. /Year: _____


Conexión eléctrica: _____

/Electric connection: 400 V. 50 Hz.

___ V. 60 Hz.

CONSERVE ESTE MANUAL PARA FUTURAS CONSULTAS

KEEP THIS GUIDE FOR FUTURE REFERENCE



INDEX

1. DESCRIPTION OF THE MACHINE.....	3
1.1 Introduction	3
1.2 General information	4
1.3 Technical data	5
1.4 Main components	6
1.5 Main dimensions	8
1.6 Hoist safety devices.....	11
1.7 Additional data of the hoist.....	11
2. ASSEMBLY OF THE MACHINE.....	13
2.1 Introduction	13
2.2 Hoist transport	13
2.3 Machine erection procedure.....	15
Step 1 Site preparation and foundation.....	15
Step 2 Base to ground positioning and fastening.....	15
Step 3 Assembly of cage and electric connection	16
Step 4 Erection of the mast.....	17
Step 5 Installing mast anchorage	19
Step 6 Installing endtrack cams and final mast	21
Step 7 Assembly of cable trolley / cable holder	22
Step 8 Installing base enclosure	23
Step 9 Assembly of landing doors	24
· SWINGING DOOR LANDING GATES (USUALLY TO SLAB)	24
· SLIDING DOOR LANDING GATES (USUALLY TO SCAFFOLD)	26
Step 10 Test of parachute	28
Step 11 Installing landing levels cams	29
Step 12 Programming landing levels.....	30
Step 13 Assembly of crane for mast erection – OPTION.....	31
Step 14 Installing landing levels call system – OPTION	33
2.4 Dismantling the hoist	33
3. USING THE HOIST.....	35
3.1 Introduction	35
3.2 Using “MANUAL” Mode	36
· A) TRANSPORT PLATFORM PT-450-2V	36
· B) TRANSPORT PLATFORM PT-450-1V	37
3.3 Using “AUTO” Mode	38
· AUTO MODE – SELECTOR “PERSONS”	38
A) TRANSPORT PLATFORM PT-450-2V	38
B) TRANSPORT PLATFORM PT-450-1V	39
· AUTO MODE – SELECTOR “ONLY LOADS”	40
3.4 Safety messages in display	41
3.5 Emergency lowering.....	42
3.6 Checking hoist operation before commissioning	43
3.7 Applications and uses forbidden	43

4. SAFETY DEVICE. PARACHUTE FPC-500	45
4.1 Introduction.....	45
4.2 Features.....	46
4.3 Installing the parachute.....	47
4.4 Parachute testing	48
4.5 Actions to take if safety device is activated	50
4.6 Revision and replacement of parachute	50
5. MAINTENANCE OF THE MACHINE	51
5.1 DAILY Maintenance	51
5.2 PERIODIC Maintenance schedule	52
5.3 Instructions for troubleshooting	55
5.4 Maintenance record	56
5.5 Trouble record.....	58
LOAD WEIGHT CONTROL CALIBRATION INSTRUCTIONS	
TEST CERTIFICATE	
EC DECLARATION OF CONFORMITY	
TÜV-PARACHUTE CERTIFICATE	
ELECTRICAL SCHEME	
ELECTRICAL PARTS	
SPARE PARTS LIST	

The user's manual must be kept in good condition. This document contains 60 pages.
 ALBA MACREL GROUP, S.L. reserves the right of incorporating contents or modifications at any time with the purpose of improving both the machine and the information available on the same.



Copyright © ALBA-MACREL GROUP, S.L.
 Rev.1.0: July 2019

1. DESCRIPTION OF THE MACHINE

1.1. Introduction.

Prior to erection and use, all users must read this manual. A thorough reading is recommended for full compliance with safety regulations.

This manual is delivered with the transport platform and its purpose is to give instructions for proper handling during transportation, erection and maintenance, in compliance with the provisions of EU Directive 2006/42CE on safe machinery. This instructions manual deals with proper use of the machine as well as proper erection and maintenance.

The manufacturer reserves the right to modify the machine for improvements, so that differences may be found in some manual details. In any case, AMG commits to immediately adapt the manual to the improvements.

Responsibility:

AMG declines any responsibility for damages caused by improper use of the machine as a consequence of non-compliance with the provisions of the present Manual. AMG declines any responsibility for damages derived from:

- Non-compliance with the provisions of this manual.
- Improper use of the machine.
- The use of non-original spare parts mentioned in the applicable section of this manual.
- Modifications introduced without express authorisation from the manufacturer.
- Handling by personnel not trained for this purpose.

Only appointed trained personnel may use the machine and only qualified technical personnel acquainted with the machine may operate on any part of the same.

This manual must be available to the user at any time for any type of immediate consultation. In order to maintain it in perfect conditions, keeping always a copy close to the machine is recommended.

In any case, the manual is aimed at knowledge strengthening and as a reminder for the personnel, who must previously be well trained by engineers or supervisors, who at the same time must be very experienced in this machine operation.

1.2. General information.

It's based on the principle of geared motor transmission to a rack and pinion mechanism. Components are modular and easy to install. It is simple to use and safe for facade work or rehabilitation, significantly reducing the erection time and man-hours.

This machine has been designed for temporary installation on site, and must be used by skilled authorised personnel. Its main advantage is the ability to connect different building stories for lifting or lowering materials and persons in a fast and safe way. Below, please find the main points to bear in mind prior to erection and use of the machine.

- The hoist is designed (CE-model) **for transporting persons and loads**, in open cage, travelling with a minimum gap of 0,5 m. from supporting structure, and vertical speed limited to 12 m/min. When using for transport of persons, cage control will be with "hold-to-run" pushbuttons. Platform also can be used for **transporting loads**, with exterior control board (ground) and increased speed to 20 m/min. In each case follow the conditions of use stated in this manual.
- The machine runs vertically, geared to the mast rack and guided with support rollers.
- Machine operation must be carried out by **appointed personnel** trained in transport platform operation, and the instructions to operate the machine safely.
- Travelling on the hoist is allowed only for **authorized passengers**, instructed by the operator appointed to management of the platform.
- For erection, dismantling, maintenance and repair tasks, only **competent and authorised technical personnel**, trained and qualified with practical experience on said operations, are allowed to travel on the hoist.
- The transport platform enables a mode of operation from the outside as hoist only for loads. When using as hoist for loads, loading and unloading operations must be performed by **instructed people**.
- The machine is designed to tie at appropriate intervals to a supporting structure, as the slabs of the floors of a building, an metallic structure or similar. AMG include in this user's manual all the information regarding to reaction forces to the structure and to the base ground. It is the responsibility of the responsible technicians on site, to ensure that, both supporting structure and base ground support transmitted loads.

WARNING SYMBOLS:



IMPORTANT SAFETY INSTRUCTIONS DURING INSTALLATION OR OPERATION IS TO BE ENTERED IN TEXT BOXES LIKE THIS, INCLUDING THE WARNING SIGN.

1.3. Technical data.**TECHNICAL FEATURES:**

	PT-450-2V	PT-450-2VM	PT-450-1V	PT-450-1VM
Motor control:	VARIADOR FREQ.		DIRECTO	VARIADOR FREQ.
Vertical speed:	12÷20 m/min.		20 m/min.	
Maximum capacity:	450 Kg. 2 pax + 250 Kg.		450 Kg. 5 pax	
Cage dimensions (LxWxH):	1.240 x 840 x 2.020 mm			
Maximum height (*):	90 m.			
Anchorage each (max.):	6 m.			
Height over las anchorage:	1,5 m.			
First anchorage height:	4 m.			
Loading height to ground	400 mm.			
Mast:	Tubo cuadrado			
Lenght:	1,5 m.			
Weight – 1 Rack:	39 Kg			
Maximum load (assembly):	200 Kg.			
Normative reference:	EN-16719 ; 2006/42/CE		EN-12518-1	

(*) For higher heights, consult the manufacturer. In case of single-phase power, consult limitations.


ELECTRICAL DATA:

	PT-450-2V	PT-450-2VM	PT-450-1V	PT-450-1VM
Motor power:	2,2 KW		2,2 KW	
Input power connection:	3~ 380÷460V 50/60 Hz.	1~ 220÷250V 50/60 Hz.	3~ 400V -50Hz 440V -60Hz	1~ 220÷250V 50/60 Hz.
Power consumption:	4 KW	2,2 KW	2,2 KW 2,65 KW	2,2 KW
Nominal current:	6 A.	13A	6 A.	13A
Supply power:	8 KVA.			
Overload protection (*):	3 x 16 A.		2 x 16 A.	
Differential protection (*)				
Calibre:	25 A.			
Sensitivity:	300 mA.			
Control voltage:	48 V.			
Auxiliary handtools socket:	230 V – 50/60 Hz. 1200 W.			
Cable section:	4 x 4 mm ²	3 x 4 mm ²	4 x 4 mm ²	3 x 4 mm ²

(*) Elements required on main feed switchboard


ACOUSTIC DATA**A-weighted emission sound pressure level, LpAd****Place: Operation point****<70dB**

1.4. Main components.




ASSEMBLY EXAMPLE TRANSPORT PLATFORM


- MAST BASE SUPPORT:**
 Main structure that is used as a support for the hoist and for the column of masts. It transmits the efforts generated to the ground and it's surrounded with a safety enclosure that avoids the risk of damage. The base incorporates absorbers to avoid blows of the cabin with the base. In the base of the machine it's also installed the electrical switchboard for electrical supply.
- MAST:**
 Modular structure for the ascent of the machine. It consists of a modular triangle structure of 1,5 m. The mast has a welded rack for the movement of the platform over it. They are designed for his union by means of screws and for the anchorage to a vertical structure of support to suitable intervals.
- MOTOR GROUP:**
 Structure that incorporates and the system of motorgear system and that provides the movement to the elevator. It incorporates both the motorgears and the safety systems to control the movements of the machine, the overload system, and the floor selector. It fits to the cabin by means of bolts.
- CAGE:**
 Metallic open structure for the transport of persons and loads. It includes doors for the loading and unloading of the machine, and auxiliary catwalk for assembly operations, all of them equipped with safety microswitches.




- ANCHORAGE:**
 System of mast anchorage to a external support structure. It consists in a bracket screwed to and a pair of telescopic pipes for adjusting to external support structure.
- POWER SWITCHBOARD:**
 It contains the principal components of the electrical equipment of the machine, and communicates both the cage control panel, and the control and power supply board on the ground, with proper connectors.
- CABLE BIN:**
 Keep the cable of the machine during the movement. The cable bin stores the communication cable coiling it.
- FINAL MAST MODULE:**
 Mast module without rack that is installed in the top limit of the column of masts. It prevents that the machine exceeds the top limit of the mast and its red color allows immediate identification.

1.5. Main dimensions.







MAIN DIMENSIONS. TRANSPORT PLATFORM



SQUARE MAST 098.2



LANDING GATE WITH SLIDING DOOR



LANDING GATE WITH SWINGING DOORS

1.6. Hoist safety devices.

- a) Gearmotors with **electromagnetic brakes** (friction type) capable to brake speeds of 20 m./min. (and even 25% overspeed) with a delay of 0.1 up to 0.2 g. with maximum load.
- b) Rubber buffers to damp eventual frame impacts against the base.
- c) Cage roof finished in hot galvanized steel.
- d) Upper and lower limit switches. Stop the lowering and lifting movements of the cage when reaching the lower and upper stops located at the first and next to last masts.
- e) Safety limit switch. Operate in case of failure of upper or lower limit switches.
- f) Mast presence detector, to be used mainly during mast erection.
- g) Microswitches for opening the cage doors, and for landing gates with mechanical interlocking device.
- h) Electromechanical interlocking on cage load door, to avoid door opening out of ground level.
- i) Unload ramps with automatic bridge and lateral protection railing included, for safety opening from the inside/outside of cage.
- j) Landing doors interlock, prevents opening unless the cage is on landing level and ramp is opened.
- k) Limit switch to stop at 2 m elevation. Movement under-2m with "hold-to-run"
- l) **Manual Emergency lowering** in case of power failure (operated from the cage).
- m) **Safety device (Overspeed emergency brake -PARACHUTE-)**, to control the lowering speed.
- n) Base enclosure of 1,1 m height, with a distance to any moving part of the hoist of 0,5 m. and microswitch to prevent platform movements if enclosure door is open.
- o) Platform floor of non-slipping galvanized steel.
- p) End mast (in red), without rack, to prevent the cage from running off in case of failure of other systems.

1.7. Other hoist data.

NOISE EMISSION DECLARATION		
	Condition	
	Inside cabina	Outside cage
A-weighted emission sound pressure level, L_{pA}:	70 dB	74 dB
Values determined according to the acoustic test given in EN 12158-1 with use of basic international standards EN ISO 3744 y EN ISO 4871.		
Note: Noise emission values and uncertainty represent an upper limit of the range in which the measured values are susceptible to be present.		
Temperature range for use:	-15°C – 45°C	
Relative humidity:	30 % – 90 %	
Max. height for installation:	1000 m. ^(**)	
Max. wind speed (SERVICE):	72 Km/h	
Max. wind speed (ERECTION):	45 Km/h	
Max. wind speed (OUT OF SERVICE *):	130 Km/h	

(*)Position OUT OF SERVICE corresponds with hoist at the lowest point and power supply disconnected.

(**)For installation in locations above 1000 m of height., and if the temperature exceeds 45° C, ask to manufacturer for limitations.



IN CASE OF NEED A SPECIAL CONFIGURATION OF MACHINE, OR MODIFICATION OF STANDARD FEATURES, ASK THE MANUFACTURER FOR DRAWINGS WITH SPECIFIC DIMENSIONS AND CHARACTERISTICS.

2. ASSEMBLY OF THE MACHINE

2.1. Introduction.

The following section is dedicated to the safely assembly of the machine. The installation of the hoist can only be performed by qualified personnel authorized to travel on it.



WARNING:


TO MOUNT THE ELEVATOR SHALL BE USED PROTECTIVE EQUIPMENT AGAINST FALLS FROM HEIGHT (ACCORDING TO EN 358:1993, EN 361:1993, EN 364:1993) AND IN ANY CASE A PROTECTIVE HELMET FOR THE HEAD (ACCORDING TO EN 397:1995), PLUS ADDITIONAL MEANS OF PROTECTION.



It is important to follow the instructions in detail , to avoid risks in the assembly and disassembly process. The user is obliged to observe, by himself, and for those working in the vicinity, all sources of additional risk, and to comply with all applicable safety standards for the type of equipment used.

2.2. Hoist transport.


The elevator is supplied disassembled, unless specifically indicated otherwise. For assembly of the components and safe handling of the base assembly and a correct positioning on the ground using a crane is needed.





IMPORTANT:

FOR ASSEMBLY OF THE COMPONENTS AND MOUNTING THE PLATFORM IT WILL BE USED A CRANE-TRUCK, OR IF AVAILABLE, YOU CAN USE BUILDING CRANE-TOWER.





ASSEMBLY OF CAGE. USE A CRANE O FORKLIFT



TRANSPORT HOLDER 099.18


2.3. Machine erection procedure:

• Step 1. Site preparation and foundation.


LOADS TO GROUND PT-450					
Height (h)	Hoist weight	Base + mast	Load	TOTAL (EST.)	TOTAL (DIN. Cd: 1,7)
10 m.	350 Kg.	380 Kg.	450 Kg.	1.180 Kg.	1.740 Kg.
20 m.		640 Kg.		1.440 Kg.	2.000 Kg.
30 m.		900 Kg.		1.700 Kg.	2.260 Kg.
40 m.		1.160 Kg.		1.960 Kg.	2.520 Kg.
50 m.		1.420 Kg.		2.220 Kg.	2.780 Kg.
60 m.		1.680 Kg.		2.480 Kg.	3.040 Kg.
70 m.		1.940 Kg.		2.740 Kg.	3.300 Kg.
80 m.		2.200 Kg.		3.000 Kg.	3.560 Kg.
90 m.		2.460 Kg.		3.260 Kg.	3.820 Kg.

(*) For intermediates, add 26 kg / m. to table above.



• Step 2. Base to ground positioning and fastening.



POSITIONING THE HOIST ON THE GROUND



BASE JACKS TO SOIL



FITTING TO GROUND RECOMENDATION


INSTALLATION DETAILS		
D _o	Drill diameter	10 mm
H ₁	Minimum drill depth	70 mm
H _{nom}	Min. mounting depth	42 mm
L	Anchor length	50 mm
L _r	Screw length	30 N-m





ATTENTION:
FOR HOIST POSITIONING IT'S REQUIRED A MINIMUM SUPPORT AREA WITH DIMENSIONS 2.250 X 1.600 mm, INCLUDING CABLE BIN.

MAKE SURE THE RESISTANCE OF THE GROUND TO WITHSTAND THE MAXIMUM LOADS TRANSMITTED BY THE PLATFORM.




DISTRIBUCION DE PESO / Load distribution





• Step 3. Assembly of motor group and electrical connection.



CONNECTING LOAD CELL



3~ 400/440V-50/60Hz



1~ 230V-50/60Hz



ATTENTION:
CONNECT ELECTRICAL EQUIPMENT TO MAIN SWITCHBOARD, WITH SPECIAL ATTENTION TO LOAD CELL CONNECTION TO THE PROGRAMER.
PLEASE, CONSULT THE SPECIFIC INSTRUCTIONS FOR ADJUSTING THE LOAD DETECTOR PARAMETERS ON ANEX AT THE END OF THIS MANUAL.

ONCE THE BASE GROUP IS INSTALLED, ACCORDING WITH PREVIOUS INSTRUCTION HOIST CAN BE RUN UP FOR MAST COLUMN ERECTION.

Step 4. Erection of the mast.

**ATTENTION:**

TO ASSEMBLE THE MASTS WILL USE, PREFERABLY A BUILDING SITE CRANE, OR AN AUXILIARY DAVIT (OPTIONAL). NEVER MANIPULATE THE MASTS BY HAND. IT'S RECOMMENDED TO MOUNT SECTIONS OF 6 M. (4 MODULES) ON THE GROUND, AND FASTEN THE WHOLE GROUP TO THE MACHINE WITH THE HELP OF A CRANE. THE FIRST MAST OF THE MACHINE, COUPLED TO THE BASE FRAME, INCLUDES THE NUMBER ID OF THE MACHINE.

MAST TÉCNICAL DATA

Weight: 39 Kg

Rack unión:

Welded

Mast screws:


(3x) Screw M12x90 DIN 931 8.8

Whaser A13 DIN 125


Self-locking nut M13 DIN 985

Torque (max):

85 N·m


**IMPORTANT:**

TO MOUNT THE MACHINE, AND FOR INSPECTION AND MAINTENANCE TASKS, ALWAYS USE THE "MANUAL" MODE OF OPERATION (CAGE CONTROL). SEE CHAPTER 3 BEFORE STARTING HOIST ERECTION.



85 N·m

MANUAL ASSEMBLY OF THE MASTS COLUMN



UNION OF MASTS




ATTENTION:
FIT / REMOVE MAST AND SCREWS ALWAYS AT THE SAME TIME!
NEVER RAISE THE HOIST OVER A NON-SCREWED MAST MODULE!
THEN THERE IS HAZARD OF COLLAPSE AND SERIOUS INJURY!






ATENCIÓN:
IT IS IMPORTANT THAT THE BASE IS PERFECTLY LEVELED AND MUST CORRECTLY VERTICAL. ENSURE LEVELING TO AVOID FUTURE PROBLEMS.


Step 5. Installing mast anchorage.



ANCHORAGE ASSEMBLY




FIXING TO THE SUPPORTING STRUCTURE




INSTALLATION DATA	
D _o	Drill diameter 12 mm.
H ₁	Minimum drill depth 95 mm.
H _{nom}	Minimum mounting depth 80 mm.
L	Anchor length 120 mm.
L _r	Screw length 65 mm.
T _{ins}	Torque 50 N·m

RECOMMENDED ANCHORAGE SYSTEM



INSTALLING ABOVE/BELOW SLAB TO VERTICAL TUBES/SCAFFOLD SCREWED TO STRUCTURE
ALTERNATIVE ANCHORING SYSTEMS



REACTIONS TRANSMITTED TO THE SUPPORT STRUCTURE. CHECKING INTERFERENCE




IMPORTANT:
 TRANSMITTED FORCES TO THE STRUCTURE DECREASE WHEN INSTALLATION ANGLE AND DISTANDE "D" ARE INCREASED.
 SEPARATE ANCHORAGE PLATES FROM EACH OTHER TO REDUCE TRANSMITTED LOADS TO STRUCTURE IF NECESSARY. CONSULT THE MANUFACTURER THE VALUES OF REACTIONS TO THE STRUCTURE RESULTING.




IMPORTANT:
 TO TAKE INTO ACCOUNT THE EFFECT OF THE WIND IN SERVICE IN THE
 CALCULATION OF THE REACTIONS IN THE ANCHORS, TO THE VALUES OF
 REACTIONS R_x , R_y AND TO BE ADDED A FORCE 42 Kgf. APPLIED IN THE MOST


Step 6. Installing endtrack cams and final mast.



ADJUSTING ENDTRACK CAM



LAST 2 m. SWITCH



ENDTRACK CAMS AND RED MAST POSITION



IMPORTANT:

INSTALL SUPERIOR ENDTRACK CAM ON THE LAST MAST AND THEN RED MAST WITHOUT RACK. USE VERTICAL REGULATION TO ACHIEVE BETTER STOP POINT.


CHECK IF HOIST STOP IS PROPERLY PERFORMED:

1. RAISE ("MANUAL" MODE) UNTIL HOIST STOPS. CHECK THAT THE MACHINE STOPS WHEN F.C.S SWITCH TOUCH SUPEROR CAM, AND ALSO THAT RED MAST'S NOT REACHED.


2. DESCEND ("MANUAL" MODE) UNTIL HOIST STOPS AND CHECK IF 2 m SWITCH HAS REACHED INFERIOR CAM. CHECK THAT LAST TRAVEL UNTIL Ref. Point ONLY CAN BE COMPLETED WITH "HOLD-TO-RUN" BUTTON OF CAGE CONTROL. CHECK IF THE MACHINE STOPS WHEN F.C.B SWITCH TOUCH INFERIOR CAM. (Ref. Point)

THESE TESTS ARE VERY IMPORTANT BEFORE FURTHER ASSEMBLY !!


Step 7. Installing cable holder.



INSTALLING CABLE HOLDER



INSTALACION DE GUIAS DE CABLE




CABLE ROLLING IN CABLE HOLDER

Step 8. Installing base enclosure.




ATTENTION:
INSTALLATION OF A BASE ENCLOSESE IS REQUIRED IN ACCORDANCE WITH HEREIN
ESPECIFICATION OF EUROPEAN STANDARD EN 16719:2014




BASE ENCLASURE ASSEMBLY

DOORS SWITCH CONNECTION



ADJUSTING ENCLASURE DOOR SWITCH



DOOR LATCHING




ATTENTION:
THE ENCLASURE OF THE BASE ALLOWS A PERIMETER PROTECTION OF 500 mm.
AROUND THE BASE OF THE MACHINE, TO PREVENT HAZARD OF SHEARING OR
CUTTING WHEN HOIST IS MOVING
IN NORMAL USE, DOWNWARDS MOVEMENT WILL BE STOPPED AT A HEIGHT OF
2 m. ABOVE BASE. FURTHER DOWNWARDS MOVEMENT IS ONLY POSSIBLE BY
NEW PERMANENT RESELECTION OFF "RUN" BUTTON.


Step 9. Installing landing doors.

· SWINGING DOOR LANDING GATES (USUALLY TO SLAB):


56 Kg




162.5 SWINGING LANDING DOOR 1400
INSTALLATION IN CONCRETE SLAB OR STRUCTURE




OPTION – 162.56 ACCESS RAMP




INSTALLATION DISTANCES





ASSEMBLY DETAIL




UNLOCKING – OPENING LANDING DOOR



DOOR ASSEMBLY ADJUSTMENT




CAGE DOOR OPENING




CONNECTION TO BASE PANEL

CONNECTION OF LANDING DOOR ELECTRICAL SWITCHES (S1-037)



ADJUSTMENT OF LANDING DOOR SWITCH





LANDING DOOR LATCHING

· **SLIDING DOOR LANDING GATES (USUALLY TO SCAFFOLD):**





ATTENTION:
 ADJUST DOOR POSITION SO THAT, WHEN CAGE RAMP IS DROPPED, LANDING DOOR INTERLOCK IS RELEASED AND DOOR CAN SLIDE TO OPEN.




099.5 SLIDING DOOR LANDING GATE 830

OPTION – 099.56 ACCESS RAMP (∠ 10°)




INSTALLATION DISTANCES


ASSEMBLY DETAIL



UNLOCKING – OPENING LANDING DOOR




DOOR ASSEMBLY ADJUSTMENT



IMPORTANT:
 VERIFY THAT THE LANDING DOORS CAN ONLY BE OPEN WHEN THE CAGE ACCESS RAMP IS OPEN, AND THAT THE CAGE SHOULD BE CLOSED SO IT IS POSSIBLE TO CLOSE THE CAGE ACCESS RAMP.

Step 10. Parachute testing.

 **IMPORTANT:**
AT THE END OF THE ASSEMBLY OF THE MACHINE, PRIOR TO USE, IT WILL BE
MADE A TEST ON THE PARACHUTE






 **ATTENTION:**
DANGEROUS OPERATION!

PARACHUTE TEST PROCEDURE (See Chap.4)

Step 11. Installing landing level cams.

 **ATTENTION:**
BEFORE USING THE PLATFORM, IT IS NECESSARY TO INSTALL THE LANDING CAMS IN THE MAST AT DESIRED LANDING LEVELS.



 **IMPORTANT:**
ONCE THE FLOOR CAMS ARE INSTALLED, MAX. NUMBER OF FLOOR IS TO BE PROGRAMMED IN THE CPU SYSTEM, SO THAT WAY, OPERATOR OF THE PLATFORM ONLY CAN SELECT ONE OF THE LANDING LEVELS PROGRAMMED.


Step 12. Programming landing levels.



PROGRAMMING OPERATIONS ARE CARRIED OUT FROM THE CABIN SWITCHBOARD.
IN EVERY NEW ASSEMBLY, OR IF THE ER E2 MESSAGE APPEARS, YOU MUST PROCEED REBOOT THE MEMORY OF THE CPU.

DELETE MEMORY / INITIALIZATION

- Step 1. Select MANUAL mode.
- Step 2. Place the elevator in the Reference Point (INFERIOR ENDTRACK LIMIT) (FCB).
- Step 3. Process:




- Step 4. Release KEY: 1 x  → INITIALIZATION PTO. REF. OK

MAXIMUM FLOOR PROGRAMMING



ATTENTION:
THE CONTROL ALLOWS TO MEMORIZE THE NUMBER OF FLOORS THAT HAVE BEEN INSTALLED, TO PREVENT THAT A FLOOR BE SELECTED IN OPERATION ABOVE THE LAST INSTALLED CAM.

- Step 1. Select MANUAL mode.
- Step 2. Press up from the cabin control until you leave the Reference point FCB (a few cm.)
- Step 3. Process:



- Step 4. Release KEY. 1 x  → MEMO Nº MAX. FLOORS OK




IMPORTANT:
AFTER SAVING MAXIMUM NUMBER OF FLOORS, THE HOIST MUST BE DOWN TO FCB IN "MANUAL" MODE. AFTER CHANGING TO "AUTO" MODE YOU WILL BE ABLE TO START WORKING.

NEGATIVE FLOORS

IMPORTANT:
THE HOIST ALLOWS TO DISPLAY NEGATIVE FLOORS. DEFINING NEGATIVE FLOORS DISPLACES REF. POINT TO THE LOWEST POINT OF THE ROUTE. NEGATIVE FLOORS ONLY AFFECT THE DATA SHOWN ON THE DISPLAY.

- Step 1. Select MANUAL mode.
- Step 2. Place the hoist in reference point FCB
- Step 3. Process:




- Step 4. Release KEY 1 x   MEMO NEW REFERENCE POINT IN NEGATIVE FLOOR


IMPORTANT:
WHEN DEFINING NEGATIVE FLOORS, REFERENCE POINT IS DEFINED ON THE LOWER FLOOR. WHEN PROGRAMMING MAX. NUMBER OF FLOORS MUST BE TAKEN INTO ACCOUNT OF NEGATIVE FLOORS.
 Example: PTO. REF. : -5, P.MAX: 15" THE DISPLAY SHOWS ONLY: -5 ÷ 10

Step 13. Installing landing levels call system – OPTION


ATTENTION:
CALLING THE HOIST FROM THE FLOORS WILL ONLY BE POSSIBLE WHEN THE HOIST IS FREE (GREEN PILOT OFF).





E-CPC-A CARD FOR FLOOR CALLS MANAGEMENT ON INFERIOR CONTROL BOARD




INSTALLATION OF FLOOR CALL BOXES



CALL BOX CONNECTOR IN INFERIOR CONTROL BOARD



CALL FLOOR SELECTION DISPLAY




SELECTING THE CALL FLOOR (BINARY CODE)

Step 14. Assembly of the falling object protection**IMPORTANT NOTE:**

ACCORDING TO THE STANDARD AT 16719: 2019, THE PLATFORM MUST BE EQUIPPED WITH AN FALLING OBJECTS PROTECTION. THE CEILING CAN BE REMOVABLE FOR ASSEMBLY AND MAINTENANCE TASKS, BUT ONLY WITH A SPECIFIC RISK ANALYSIS IN THE PLACE OF INSTALLATION, WHICH CONCLUDES THAT THE RISK OF FALLING OF OBJECTS THAT CAN DAMAGE PEOPLE ON THE PLATFORM IS MINIMUM, THE PLATFORM OF TRANSPORTATION COULD BE USED WITHOUT CEILING.

ALBA SUPPLIES THE PROTECTOR WITH THE MACHINE, AND THEREFORE IT IS THE RESPONSIBILITY OF THE INSTALLER TO PREPARE THE RISK ANALYSIS AND, IF APPLICABLE, THE USE OF THE PLATFORM BY THE WORKERS WITHOUT THE FALLING OBJECTS PROTECTION.

**FALLING OBJECT PROTECTION****ASSEMBLY OF THE PROTECTOR****2.4. Dismantling the hoist**

For the dismantling of elevator perform the reverse process to that described in this manual, with particular attention to the tasks that present a risk of falling.

**ATTENTION:**

FOR MACHINE DISMANTLING "MANUAL" MODE IS TO BE USED, WITHOUT LOADS, AND OPERATING THE HOIST FROM CAGE CONTROL.

Step 1. Dismantling mast column and anchorages

Remove first the red Mast and upper stop cam and then the column of masts and anchors.



ATTENTION:
REMOVE MAST AND SCREWS ALWAYS AT THE SAME TIME!
NEVER RAISE THE HOIST OVER A NON-SCREWED MAST MODULE!
THEN THERE IS HIGH CHANCE OF COLLAPSE AND SERIOUS INJURY!



Step 2. Dismantling cable system and guides

Remove the cable bracket and remove the cable guides, continuing with the dismantling of masts column to the lower limit

Step 3. Electrical devices disconnection

Once you reach the lower limit, disconnect power supply and remove electrical equipment.

Step 4. Dismantling the cage

Remove the cage releasing union bolts, by the same procedures described for mounting.

Step 5. Dismantling base frame

Release buffers, remove anchorage to ground. The hoist is ready for transport.

ATTENTION:
IMPORTANT NOTE ON COMPLIANCE WITH EUROPEAN DIRECTIVE 2006/42/CE.



CE DECLARATION OF CONFORMITY is valid only for machines purchased and installed with all original components supplied by ALBA-MACREL Group, SL and following all the instructions provided in this user's manual, ensuring compliance with all SSER Annex I of Directive 2006/42/EC.
Otherwise, the machine can't be put into service until final assembly is declared in accordance with the specifications of Annex II of the Directive.

3. USING THE MACHINE.

3.1. Introduction.



WARNING:

HOIST CAN ONLY BE USED BY THE DESIGNATED PERSONS, WHO HAVE BEEN INSTRUCTED IN THE SAFELY HOIST OPERATION

ACCESS TO THE PLATFORM FOR LOAD AND UNLOAD ONLY IS ALLOWED FOR TRAINED PERSONS

FIT THE LOAD CONVENIENTLY INSIDE THE CAGE, ESPECIALLY IF IS TRANSPORTED WITH PEOPLE TRAVELING TOGETHER.



IMPORTANT:

TWO OPERATION MODE ARE POSSIBLE WITH THE HOIST:



- "MANUAL" MODE (ONLY FOR ASSEMBLY): HOIST MOVEMENTS ARE PERFORMED WITH HOLD-TO-RUN BUTTONS. CONTROL IS ALLOWED ONLY FROM THE CAGE CONTROL (▲ ▼).

KEEP THE KEY FOR "MANUAL" MODE SWITCH OUT OF THE REACH OF ELEVATOR USERS.



- "AUTO" MODE: THE MACHINE IS USED BOTH FROM THE CONTROL ON THE FLOOR (ONLY LOADS), AND FROM THE CAGE CONTROL (PERSONS AND LOADS). THE MACHINE IS MOVING ON PROGRAMED LANDING LEVELS. (SEE LANDING LEVELS PROGRAMMING)



- HOIST ALLOWS (AS AN OPTION) A LANDING LEVELS CALLING CONTROL SYSTEM).



ATTENTION:

DUE TO SAFETY PURPOSES, WHEN DESCENDING, HOIST STOPS WHEN IT REACH 2 m. REMAINING TRACK UNTILL F.C.B. (Inferior endtrack switch) IS ONLY TO BE POSSIBLE BY HOLDING "RUN" BUTTON.

PT-450-2V: IN "PERSONS" MODE, THE CONTROL HAS A DELAY OF 3 sec. TO COMPLETE DOWNWARDS MOVEMENT OF 2 m. ZONE.



WARNING:

"MANUAL" MODE ONLY IS ALLOWED FOR AUTHORIZED AND COMPETENT TECHNICAL PERSONS, WHO WILL KEEP THE KEY TO PREVENT USE BY UNAUTHORIZED PERSONNEL.

3.2. Using "MANUAL" mode.



WARNING:
 "MANUAL" MODE IS USED FOR HOIST ASSEMBLY / DISMANTLING TASKS, AND FOR INSPECTION AND MAINTENANCE.
 HOIST HANDLING IS PERFORMED ONLY FROM THE CAGE CONTROL.
 OPERATE THE PLATFORM IN "MANUAL" MODE IS FORBIDDEN BY UNAUTHORIZED USERS.

MAKE SURE THE CAGE DOORS ARE PROPERLY CLOSED AND LOCKED BEFORE MAKING ANY MOVEMENT WITH THE PLATFORM.

A) Transport platform PT-450-2V:

DESCRIPTION OF THE CONTROLS - MANUAL MODE



MANUAL MODE ACTIVE



LIGHT - OUT OF SERVICE

START EQUIPMENT RESET BUTTON

AUTO-MAN



MANUAL MODE SELECTOR



SELECTOR NOT ENABLED




UP - DOWNLOAD MANUAL

KEY

PROGRAMMING BUTTON

RUN

LOWERING MANUAL - ZONE 2 m.



RUN



AUTO-MAN



START



KEY




ATTENTION:

ALL MOVEMENTS IN CASE OF USE OF THE MANUAL MODE WILL BE WITH THE CONTROL UP - DOWN PUSHING CONTINUOUSLY AND WITH SLOW SPEED.

B) Transport platform PT-450-1V:

DESCRIPTION OF THE CONTROLS - MANUAL MODE



MANUAL MODE ACTIVE



LIGHT - OUT OF SERVICE


START
EQUIPMENT RESET BUTTON



MANUAL MODE SELECTOR



NOT ENABLED




UP - DOWN MANUAL

KEY

PROGRAMMING BUTTON

RUN

LOWERING MANUAL - ZONE 2 m.



ATTENTION:



ALL THE MOVEMENTS IN CASE OF USING THE MANUAL MODE WILL BE WITH THE CONTROL UP - DOWN PUSHING CONTINUOUSLY AND WITH NOMINAL SPEED.



WARNING:

IN ALL MODELS, IF THE HOIST IS IN "MANUAL" MODE, THE CONTROL FROM THE BOTTOM PANEL IS DISABLED, PREVENTING THE HANDLING OF THE HOIST BY USERS.

3.3. Using "AUTO" mode.



IMPORTANT:
"AUTO" MODE IS USED FOR NORMAL HANDLING OF THE HOIST BETWEEN PROGRAMMED LEVELS, WITH BOTH CAGE CONTROL ("PERSONS") AND GROUND CONTROL ("LOADS")

· AUTO MODE – "PERSONS" SELECTOR:


A) Transport platform PT-450-2V:


DESCRIPTION OF CONTROL – AUTO MODE-"PERSONS" (MAIN CONTROL BOARD)

AUTO MODE WITH HOIST IN THE POINT OF REFERENCE



AUTO MODE WITH HOIST OUT OF THE POINT OF REFER.








LIGHT - OUT OF SERVICE



AUTO-MAN



"PERSONS" MODE



DESTINATION FLOOR SELECTION




SHIPPING TO DESTINATION FLOOR

ATTENTION:

THE MOVEMENT UP TO THE FLOOR DESTINATION OF THE HOIST IN AUTO- PEOPLE MODE WILL BE WITH THE CONTROL "RUN" PULSED IN A CONTINUOUS MANNER AND SLOW SPEED.

B) Transport platform PT-450-1V:

DESCRIPTION OF CONTROL – AUTO MODE -“PERSONS” (MAIN CONTROL BOARD)



AUTO MODE WITH HOIST OUT OF THE POINT OF REFERENCE



LIGHT - OUT OF SERVICE

AUTO-MAN



SELECTOR AUTOMATIC MODE

KEY

PERSONS MODE ACTIVATION (ACTIVE DURING 15 SG.)



DESTINATION FLOOR SELECTION

RUN

SHIP TO DESTINATION FLOOR



AUTO-MAN



START



KEY



RUN



ATTENTION:

THE MOTION TO THE FLOOR DESTINATION OF THE HOIST IN AUTO MODE – “PERSONS” MODE WILL BE AUTOMATIC AFTER PULSING "RUN", AND AT NOMINAL SPEED.



ATTENTION:

IF “AUTO” MODE IS SELECTED WITH THE HOIST OUT OF REFERENCE POINT, ONLY “TOTAL DESCEND” TO REFERENCE POINT IS ALLOWED. ONCE THE HOIST UN ON REFERENCE POINT, IT CAN BE COMMISIONED AGAIN.



ATTENTION:

IF OPERATOR TURNS CONTROL FROM AUTO – “PERSONS” TO AUTO – “ONLY LOADS” HOIST WILL REMAIN “OCCUPIED” FOR 15sg. AFTER THAT TIME, LOWER INFERIOR CONTROL PANEL FOR USE AS “ONLY LOADS” HOIST IS ENABLED.

· AUTO MODE – “ONLY LOADS” SELECTOR (ALL MODELS):

DESCRIPTION OF CONTROLS – AUTO MODE-“ONLY LOADS” (GROUND PANEL)



AUTO MODE WITH HOIST IN THE POINT OF REFERENCE



AUTO MODE WITH HOIST OUT OF THE POINT OF REFERENCE.



LIGHT - OUT OF SERVICE



MODE “SOLO CARGAS” (ON CAGE)



SELECTION OF DESTINATION FLOOR BUTTONS

RUN

SHIP TO DESTINATION FLOOR












ATENCION:

THE MOTION TO THE FLOOR DESTINATION OF THE HOIST IN AUTO MODE – “ONLY LOADS” WILL BE AUTOMATIC AFTER PULSING "RUN", AND AT NOMINAL SPEED.




ATTENTION: MODEL PT-450-2V
 WHEN “AUTO” MODE IS SELECTED, PERSONS USE (CAGE) OR LOADS USE (GROUND) HAVE TO BE CHOSEN.
 ANY EXCHANGE PERSONS - LOADS SELECTOR WHEN THE PLATFORM IS IN MOVEMENT, IS EFFECTIVE ONLY AFTER FINISHING THE CURRENT MOVEMENT.




ATTENTION: (ONLY MODEL PT-450-1V)
 TO ENABLE CAGE CONTROL “KEY” BUTTON’S TO BE PRESSED. HOIST CONTROL FROM CAGE (PERSONS) IS ALLOWED FOR 15 SEC, ANNULING GROUND PANEL.
 AFTER 15 SEC. WITHOUT ORDER FROM CAGE CONTROL, CONTROL RETURNS TO GROUND PANEL.

OTHER MESSAGES ON DISPLAY



MANUAL Mode selected



Total descent to FCB (Ref. point) and RESET



Total descent to FCB (Negative Ref. point)



Memory error (ERASE MEMORY)



Reset control (PRESS KEY en FCB)



Hoist in AUTO mode and in FCB


3.5. Emergency lowering

In case of power failure without the possibility of restoration, you can descent the cage handpicked , acting WITH EXTREME CAUTION on the release levers of the motor brakes on the cage roof. This must be done in small intervals to avoid machine acceleration.



CAUTION: DANGEROUS TASK

IF SAFETY GEAR SPEED IS EXCEEDED, PARACHUTE IS AUTOMATICALLY ENGAGED, BLOCKING ANY FURTHER CAGE MOVEMENT UNTIL TECHNICAL ASSISTANCE.



BAJADA DE EMERGENCIA
EMERGENCY LOWERING
DESCENTE D'URGENTE



WARNING:

CASE OF PARACHUTE ACTIVATION HOIST SERVICE WILL BE SUSPENDED AND TECHNICAL SERVICE WILL BE NOTIFIED FOR INSPECTION AND HOIST RELEASING.

3.6. Checking hoist operation before commissioning.




IMPORTANT:

BEFORE HOIST COMMISSIONING, HOIST SERVICE RESPONSIBLE WILL CHECK IF HOIST IS IN COMPLIANCE WITH FOLLOWING POINTS:

- Hoist 's installed with all operational safety systems:
 - Landing floor are properly programmed
 - No destination can be chosen over last floor programmed.
 - FCS microswitch stops hoist before reaching red mast.
 - Overload detector (inductive sensor) works properly
 - Brakes support the maximum load correctly.
 - FCB microswitch stops hoist on Ref. Point before reaching buffers.
 - The mast presence detector works correctly.
 - Display shows safety activations and operacional leds correctly.
 - Landing levels hoist calling system works OK (if installed).
 - Hoist control inside cage works properly

- There's no interference of hoist and external items, mast, ties, supporting structure,..
- Landing doors are installed and there's no interference with hoist mobile elements.
- Base fence is installed and there's no interference with hoist mobile elements.
- Door releasing system for cage door / landing door / fence door are operative.



- Control microswitch for cage door / landing door / fence door work correctly
- The points of access to the platform and hoistway have adequate lighting.



IMPORTANT:

KEEP ORDER AND CLEANING IN THE ELEVATOR AND SURROUNDINGS

3.7. Applications and uses forbidden


- DON'T use the hoist on explosive atmospheres.
- DON'T use the hoist with higher load than shown in the plate
- Load CAN'T be piled up at the cage floor bounds, **it must be located as near from mast as possible.**
- DON'T transport loads out of cage floor.
- DON'T use the hoist in adverse weather conditions, rain, ice, snow, (See Ap. 1.3) ...

- DON'T use the hoist in unacceptable physical condition, treatment of serious illness, under alcoholic drinks effects, or under stress or mental overload condition.
- DON'T use the machine with other parts than those originals from the manufacturer.
- DON'T work without the necessary personal protection gear. These safety devices will vary upon different conditions, therefore, a qualified person in the requirement of safety and health must evaluate the working conditions and mode of use before starting works.
- DON'T access the elevator with inappropriate clothing, hanging chains, rings or loose long hairs.
- DON'T put raised brackets on the cage floor. If travelling, user's feet must be on the cage floor.
- DON'T use the hoist if the key switch has been forgotten in the lock and can be manipulated.
- DON'T dismantle integrated equipment whose maintenance is only allowed authorized personnel (ej.: electrical motor, brake, gear-reductor).
- DON'T manipulate electrical system without express permission of the manufacturer.
- DON'T use the hoist without a differential switch on the main power supply connection line.
- DON'T use the machine with personnel traveling in the basket in MANUAL mode, except in the case of maintenance tasks and by authorized personnel.
- Do not use the machine under insufficient lighting conditions. If necessary, local lighting will be installed at access points, illuminating the hoistway. You will also install local lighting in the control panel area, that allows the correct vision of the elevator controls as needed, using the auxiliary power outlet available in the upper part of the panel.

4. SAFETY DEVICE. PARACHUTE FPC-500

4.1. Introduction.

According to the specifications of Directive 2006/42/EC, the hoist must have a safety device for mechanical locking to act if the speed exceeds a set value. Parachute safety system is a mechanical unit designed to prevent accidental loss of the machine. The system only operates during the fall, when the speed exceeds a predetermined value, acting as a hoist speed traker, not making any effort on to lift device, during normal operation of the machine.



ASSEMBLY OF PARACHUTE. GENERAL DESIGN

4.2. Features

A parachute works by blocking the drop in the case of there is a speed rising over the nominal value. The overspeed detection system is based on the principle of action of the centrifugal force to engage driven pinion into the elevator structure. Its main components are as follows:

• **Cover:**

The parachute has a waterproof housing that allows confining the security unit, preventing it from dust and corrosive atmosphere inside. It must also prevent unauthorized adjustment, so that should not be screws handling by unauthorized persons.

• **Buffer:**



The parachute has a progressive braking system so that locking is produced in a buffered way, so that after a controlled braking, the cage is stopped, according to deceleration specifications of reference standards to avoid accidents resulting from major efforts generated by moving mass inertia.

• **Locking:**

The device features a brake consisting of four sectors, which are charged up to torque referred to the elevator, so that deceleration is controlled accurately, even in case of free drop of the machine, according to the specifications of harmonized standards reference.

• **Integrated microswitch:**

The parachute includes a microswitch that is activated in case of brake locking, allowing the signal to cut the movement of hoist and preventing further operations of the machine, until the action of a person designated to release the hoist.



SAFETY SWITCH AND INTERNAL CONNECTION

ID plate and features of the device:

The parachute is equipped with an identification plate, with CE logo stamped and brake characteristics:


- Brake type, mounting position and lock sense.
- Locking speed (r.p.m.) and brake torque (N·m)
- Number, date and reference of manufacture.



ID PLATE ON THE PARACHUTE

4.3. Installing the parachute.

The unit shall be firmly fixed to the chassis of the cage, so that the pinion is centered with the fitting hole, to rotate at the speed of normal movement of the elevator. The unit must be fitted to the hoist with all screws and safety washers



INSTALLING SAFETY UNIT IN TO THE HOIST



WARNING:

A PARACHUTE SHOULD NEVER BE MOUNTED ON A HOIST OF DIFFERENT CHARACTERISTICS THAN THOSE INDICATED ON THE PLATE.



WARNING:

HANDLING AND TESTING OF THE PARACHUTE ONLY IS ONLY ALLOWED TO THE MANUFACTURER OR AUTHORIZED SERVICE PERSONNEL.

Finally, install the safety switch wire on its correct position, according to the scheme, in order to avoid further movement of the hoist if the safety device locks, until the actuation of technical personnel.

Once the assembly of the unit is finished, install back cover, so the device remains watertight and mechanical characteristics of the parachute are preserved along the time. Nobody but the manufacturer is allowed to manipulate screws of the unit itself.

4.4. Ensayos del paracaídas

In accordance with the reference harmonized standard, tests on the parachute have to be performed, in order to verify its functioning properly.

A) MANUFACTURER TEST

ALBA MACREL GROUP, SL perform a test on each lift during the machine assembly to ensure the safety and proper functioning of the device. The test result is reflected in the TEST CERTIFICATE, which accompanies this manual of the machine.

B) USER TEST

Periodically, **every 4 months**, or **after each assembly machine on site** a functional test of the parachute shall be performed, in accordance with the instructions set out below. The test of the parachute must be further supplemented with a brake inspection, checking the correct appearance of all the elements and the sealing of the outer cover. This process is repeated more often if the machine operates in extreme environmental conditions.


PARACHUTE TEST PROCEDURE

INSTRUCCIONES PARA LA REALIZACIÓN DEL ENSAYO:



WARNING: (ONLY FOR PT-1V)
FOR SAFETY PURPOSE, RELAY HEAD "RDP" IS NOT MOUNTED. INSTALL IT BEFORE TEST, THAT WAY TEST BOARD WORKS. AFTER TEST, REMOVE "RDP"


- 1.- The area under the machine must be free of people and obstacles.
- 2.- The hoist shall be securely fastened to the facade or structure.
- 3.- Remove parachute bridge of the mainboard and connect instead the parachute test board.
- 4.- Leave the hoist and load the cage with $\frac{1}{2} \cdot Q_n$ (± 500 kg.) and take a position at a safe distance.
- 5.- Raise the hoist with test board and stop it at approx. 3 m. above the ground.
- 6.- Turn on the left "TEST" key and let the hoist drop until parachute activates and cage stop. Check if elevator stops after a little slip, and then it's blocked for further descent movements.



- 7.- To release the parachute, it's necessary to press "UP" for a while, until display shows RESET. Then hoist can be recovered and must be descended to reference point. After pressing "KEY" button to reset, the hoist is released and can be commissioning again.




IMPORTANT:
CHECK THE PARACHUTE PERIODICALLY AND WRITE THE RESULT IN THE OPERATOR'S MANUAL REGISTRATION.



 **ATTENTION:
DANGEROUS OPERATION!**



max. 3 m.



4.5. Actions to take if safety device is activated

The parachute is activated in case that the emergency lowering speed exceeds normal download speed of the hoist. This can only happen in the following cases:

- A) Case of power failure or electrical malfunction, and it is necessary to descent the hoist manually, using the manual lever to release the brake of motor, and this procedure is performed without taking into account the information in this manual operator, exceeding the speed of the parachute jump
- B) Case of accident or structural failure that causes gear pinion disengage or gearmotor shaft breaking or any of its elements.
- C) Case of parachute testing.

Case of scenario A or C, the person who performs emergency descent will be a qualified technician who is trained to release device and reset the **hoist**. This requires connecting the keypad to test and reset parachute.




ATTENTION:
MOTOR BRAKE MANUAL RELEASE ONLY IS ALLOWED TO TECHNICAL PERSONNEL AUTHORIZED TO TRAVEL ON THE ROOF OF THE CAGE.

In the case of occurrence of case (B) shall cease machine operation until the action of an authorized technician which choose the best option depending on the severity of problem. If there is no clear solution, perform the disassembly of the machinery with auxiliary means.

4.6. Revision and replacement of the parachute.

Following the instructions of the safety device manufacturer, in order to ensure integrity of the device, along the time, the responsible of the hoist must proceed as follows:

- 0. Installation of the device on the hoist. Drop test to check.
- 1. After **4 YEARS**: The parachute has to be shipped to manufacturer for revision and recalibration.
- 2. After **8 YEARS**: The parachute has to be shipped to manufacturer for revision and recalibration.
- 3. After **12 YEARS**: Replace the parachute of the hoist.



Fecha de instalación: Installation date: Date de installation:	03-2019
Fecha de revisión 1: Revision date 1: Date de revisión 1:	03-2023
Fecha de revisión 2: Revision date 2: Date de revisión 2:	03-2027
Fecha de sustitución: Replacement date: Date de remplacement:	03-2031

INSTALLATION, REVISION AND REPLACEMENT PLATE

· Additional information of device: <https://www.eide.net/en/productos/fpc-overspeed-safety-brake/>



IMPORTANT:
AFTER REPLACEMENT OF THE PARACHUTE, DROP TEST OF THE NEW DEVICE MUST BE PERFORMED. WRITE THE RESULT IN THE USER'S MANUAL LOG.

5. MAINTENANCE OF THE MACHINE.

**WARNING:**

BEFORE PERFORMING ANY MAINTENANCE ACTION, TURN THE POWER OFF AND IF REQUIRED, BLOCK VERTICAL MOVEMENT AT LEAST 1.8 m. HEIGHT UNDER THE CAGE. MAINTENANCE TASKS MUST BE PERFORMED WITHOUT LOADS.

5.1. DAILY Maintenance.

Daily maintenance includes basic operations of visual inspection in the hoist, performed by the person responsible of the hoist on the building. Every day, prior to use, visual inspection of the elevator should be done, according to the following service points:

- There's no accumulation of ice, snow or debris inside the cage, or near the hoist.
- There's no excessive wear in the rack, or in the vertical pipe of the mast.
- All the cage protections are installed, and there's no dangerous holes or gaps.
- Identification and characteristics plate is installed inside the cage.
- Zone below hoist is bounded and base fence is installed.
- There isn't any warped or cracked part (Case of, change it).
- Electrical wires are correctly installed and tightly guided on the hoist.
- Guide rollers are in touch with mast tube and without excessive wear.
- There are no power lines near the hoist that endanger people or machine.
- There are no outgoing elements in the facade that may interfere with the machine.
- Electrical safety devices are operational (doors, Endtrack switch, mast sensor).
- Emergency stop works properly.
- Facade anchorages are correctly installed.
- Cage door, fence door and landing door auto-lock system work properly.
- Cage floor and walls are in good condition.
- Rack-pinion transmission is correctly engaged.
- Control and power boards are in good condition
- Cage lamp lights properly.
- All the controls, panels and indicators work properly.
- Cable travels and slides over the cable holder properly.

After reviewing all the checkpoints listed, and solved any problem, the machine can be used safely.



5.2. PERIODIC Maintenance Schedule






WARNING:
IN CASE OF ELECTRICAL MALFUNCTION IN THE HOIST, DO NOT HANDLE ELECTRICAL EQUIPMENT. MAINTENANCE AND INSPECTION OF THE HOIST ONLY MUST BE PERFORMED BY AUTHORIZED



Maintenance of the lift must be performed by the staff responsible for the machine and the results have to be recorded on the MAINTENANCE RECORD.


MAINTENANCE TASKS SCHEDULE			
OPERATION	ELEMENT	TOOL	PERIODICITY
1	 <ul style="list-style-type: none"> • FIXING BOLTS CAGE-CHASSIS (CHECKING). • ENDTRACK CAMS. • MAST SENSOR (CHECK GAP: ±5 mm.). • MOTORGear OIL LEVEL. • DOOR MICROSWITCH • LOAD CELL (CHECK FUNTION) • SWITCHBOARD LIGHTS ANS BUTTONS. • MAST TUBE (WEAR OR WELDING FAILURE) • MOTOR BRAKE RECTIFIER (CHECK FUNCTION) • COMMUNICATION CABLE (INSPECTION) • GUIDE ROLLERS (INSPECTION). • ANCHORAGE (CHECK INTERFERENCE OR LOOSENING) • BASE BUFFERS (INSPECTION) 	-	40 h.WORK (ONCE A MONTH)
2	 <ul style="list-style-type: none"> • MAST RACK • GEARMOTOR PINION. • PARACHUTE PINION. 	LITHIC GREASE	40 h.WORK (ONCE A MONTH)
3	 <ul style="list-style-type: none"> • MAST SCREWS. • GUIDE ROLLERS SCREWS. • BASEFRAME TO GROUND SCREWS. • ANCHORAGE TO SUPPORTING STRUCTURE SCREWS 	SPANNER	QUARTERLY (4 TIMES/YEAR)
4	 <ul style="list-style-type: none"> • MAST RACK DIMENSION CHECKING • GEARMOTOR PINION CHECKINGS • BRAKE MOTOR CHECKING 	CALIBER MICROMETER GAUGES	ANNUAL (OR AFTER DISMANTLIING)
5	<p>GENERAL REV. <small>(AFTER DISMANTLING OR PROLONGED NON USE PERIOD)</small></p> <ol style="list-style-type: none"> 1. DEFORMATION OR DAMAGE ON MASTS, ANCHOR, DOORS, HANDRAILS, FLOOR,... 2. GEARMOTOR AND BRAKE INSPECTION (Rectifier, Voltage & Coil resistance) 		

MECHANICAL CHECKING DIAGRAM




$K_2 \text{ TOOTH} < 21 \text{ mm} \rightarrow$ REPLACE PINION

$h < 3 \text{ mm} ; H < 28 \text{ mm}$ REPLACE MAST





ROLLER REPLACEMENT



ROLLER REPLACEMENT

- M06 - 10 N·m
- M08 - 24 N·m
- M10 - 50 N·m
- M12 - 85 N·m
- M16 - 210 N·m
- M20 - 410 N·m





TIGHTENING TORQUE


MAST DAMAGE CHECKING

ELECTRICAL AND GREASING CHECKING DIAGRAM

EN CAJA DE BORNAS / INSIDE TERMINAL BOX



MOTOR BRAKE RECTIFIER TESTING
(WITH MACHINE WORKING)



GEARMOTOR OIL LEVEL

- Type: Synthetic; Quantity: 0,9 l.
- PGLP ISO VG 220: -35°C.< T^a < 100°C.
- PGLP ISO VG 460: -15°C.< T^a < 100°C.

BRAKE CHECKING:

- Air gap (GAP):..... 0,3 +0,45 mm.
- Hand lever gap (g):..... 0,6 mm.
- Min. brake disk thickness:11 mm.

FUNCTION CHECKING:

- Check rectifier output voltage: 103 V. DC (±5 V)
- Check brake coil resistance: (check value)

AIR GAP ADJUSTMENT

1. Loosen Nb.32 nuts
2. Tight screws Nb. 25
3. Measure with gauge on 3 positions 120° next to guiding bushes 28
Retighten nuts Nb. 32 keeping Nb. 28 screws position.


GEARMOTOR PERIODICALLY MAINTENANCE:

1. WITH MACHINE OUT OF SERVICE:

- Check absence of oil, dirt and machining residuals
- Check cooling air zone
- Check oil level and quality
- Check Fitting bolts torque
- Check correct tightening of electrical connections

2. WITH MACHINE WORKING:

- Check abnormal noise emission or vibration.
- Check oil gaskets and oil leak.
- Correct work of electrical brake



GREASING POINTS



ATTENTION:
REPLACE THE WHOLE GEARMOTOR OIL, AT LEAST, EVERY 4 YEARS.
USE SYNTETIC OIL WITH RELATED CHARACTERISTICS.

5.3. Instructions for troubleshooting

Problem	Probable cause	Solution
Hoist doesn't run (OUT OF SERVICE RED LIGHT ON)	<ul style="list-style-type: none"> • Safety device activated • Frequency inverter error (KA2) • E3 Shut down • Phase error /unbalanced phase 	<ul style="list-style-type: none"> • Check safety systems: <ul style="list-style-type: none"> - Emergency stop (SE) - Safety microswitch FCSeg. • Check frequency inverter • Rearm E3 • Change supply phase connection
Hoist moves doing abnormal noise or it doesn't smoothly	<ul style="list-style-type: none"> • Guide roller damaged • Lack of grease in pinion . • Lack of grease in mast rack 	<ul style="list-style-type: none"> • Check guide rollers and bearings. Change if required. • Apply grease to the rack
Hoist slides when charging loads	<ul style="list-style-type: none"> • Trouble, brake wear • Overload 	<ul style="list-style-type: none"> • Sustituir /regular el freno del motor • Remove overload
Electrical motors starts very slowly	<ul style="list-style-type: none"> • Brake doesn't work • Overload • Innadequate electrical voltage 	<ul style="list-style-type: none"> • Check / Replace electrical brake • Check load on the cage • Check electrical voltage
Hoist doesn't stop in upper /lower limits, or on landing floors	<ul style="list-style-type: none"> • Trouble at landing cams • Problem in inductive sensor 	<ul style="list-style-type: none"> • Check landing level cams installation • Check inductive sensor function
Hoist doesn't stops on 2m switch / cam	<ul style="list-style-type: none"> • 2 m. microswitch problems 	<ul style="list-style-type: none"> • Check 2 m. microswitch and cam
E2 or E3 shut down	<ul style="list-style-type: none"> • Transformer trouble 	<ul style="list-style-type: none"> • Check / Repace transformer
E4 shut down	<ul style="list-style-type: none"> • Brake rectifier fault 	<ul style="list-style-type: none"> • Check / Repace rectifier
Hoist stops suddenly	<ul style="list-style-type: none"> • Overload • Power supply failure • Door open 	<ul style="list-style-type: none"> • Check load on the cage • Check electrical connection • Check landing doors and cage doors
Hoist cage vibrates abnormally	<ul style="list-style-type: none"> • Non tightened screws. • Rack-pinion gear problem • Lack of lubrication • Mast tube pipes wear 	<ul style="list-style-type: none"> • Check guide rollers adjustment • Check rack-pinion gear • Lubricate rack and pinion • Check mast for tube wear
Hoist slides down	<ul style="list-style-type: none"> • Excessive brake wear • Wrong brake adjustemnt 	<ul style="list-style-type: none"> • Check brake adjustment • Check rectifier fuction
Gearmotor sounds / vibrates abnorm.	<ul style="list-style-type: none"> • Lack of oil in the motorbox • Gearbox bearing failure 	<ul style="list-style-type: none"> • Check oil level • Check for oil leaks • Alert motor technical service
Hoist suffer stops when moving	<ul style="list-style-type: none"> • Communication cable damaged • Endtrack or door switches unadjusted 	<ul style="list-style-type: none"> • Check communication cable • Check microswitch adjustment
Hoist can't raise rated load	<ul style="list-style-type: none"> • Crossection wire inadequate • Motor brake damaged • Supply voltaje inadequate 	<ul style="list-style-type: none"> • Check communication cable • Check / replace motor brake • Check voltaje supply
Hoist doesn't raise / descent	<ul style="list-style-type: none"> • LED panel indication • Cage / external doors • Endtrack limits detectors 	<ul style="list-style-type: none"> • Check LED panel information • Check cage and landing doors • Check FCB / FCS /FC floors detectors
Hoist doesn't memorice floors	<ul style="list-style-type: none"> • Electronic CPU card damaged 	<ul style="list-style-type: none"> • Replace CPU card



ATTENTION:
CHECK IF HOIST IS CONNECTED TO A POWER SUPPLY EQUIPED WITH DIFFERENTIAL PROTECTION 300mA.



INFORMATION:
IF YOU REQUIRE TECHNICAL ASSISTANCE FOR GEARMOTOR, YOU CAN CONTACT THE MANUFACTURER, OR THE SERVICE MOTOR MANUFACTURER IN EACH COUNTRY. SEE CONTACT POINTS: <http://www.rossi-group.com/>

5.4. Maintenance record.

According to the procedure specified in the user’s manual, the responsible for maintenance of the hoist should fill this table according to the frequency indicated, for the record of scheduled tasks.

Nº	DATE	TASK DESCRIPTION	NAME	SIGNATURE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				

Nº	DATE	TASK DESCRIPTION	NAME	SIGNATURE
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				
86				
87				
88				
89				
90				
91				
92				
93				
94				
95				

5.5 Trouble record

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

.....

Place Date

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

.....

Place Date

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

.....

Place Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

.....

Place Date.....

TYPE OF FAILURE:

Cause:

Reparations performed:

.....

.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

Place Date

TYPE OF FAILURE:

Cause:

Reparations performed:

.....


.....

PARTS TO CHANGE					
Code	Denomination	Quantity	Code	Denomination	Quantity

ALBA authorized technical person User

Place Date

Installation



Keys of access to the parameters of menu's

The unit has a menu to accede to the adjustment of the parameters.

MENU Pressing this key successively, will go going to all programmable parameters of the menu in a cycle way.

To return to the visual presentation of weight, press the key several time till to arrive at the end of the menu, or just press it during 2 seconds.

Note: If when entering in the menu appears **[CLRW]** in intermittent, the unit has set a key and it is necessary to introduce your keycode in this moment in order to modify the parameters.

→ Pressing this key enters in the selected option and once inside we will be able to select the digit to modify.

Note: In the event of not being able to enter, it means that the key is protected. And it is necessary to introduce your keycode.


See section N° 8 (Auxiliary functions **[CLR]**)

↑ Pressing this key will modify the selected digit.

Also by pressing this key when you are located on the selected parameter, the display presents its content.

Note: 1) The only content that you'll not see is the parameter **[PESO]**

Programming Structure of the Menu's



Modification of the parameter

- 1) Go pressing the key **MENU** successively until being placed on the desired parameter.
- 2) Press the key **→** to enter in *modification of the parameter*, being the left digit in intermittent.
- 3) Put in the display the wanted value, using these keys **←** **→**
- 4) Press **MENU** 2 times to save the assigned value. Then the display will present the next parameter.

Notes:

- a) If you haven't press the **MENU** for the 2nd time, the operation will not be stored, and the display presents again the parameters that you were modifying.
- b) To modify the parameters **[PESO]** & **[CELL]**, please consult section N° 6 (Calibration of the unit)

Calibration of the Unit.

This section is necessary so that the unit knows the relationship between the signal of the cell and the weight introduced in the cabin.

1) Setting of the Zero:

- a) Situate in the option of menu **[CEQ]**
- b) Check that the cabin is empty and press the key **→**. The display menu **[CEQ]** will become intermittent during 10 seconds.
- c) Press again the key **MENU** while it is in intermittent the operation will be confirmed with a count-down. And when it finished, the display will present the parameter **[PESO]**

Note: If you don't press the **MENU** before finishing the intermittence, the operation will not be stored, and the display presents again the parameter **[CEQ]**.

2) Adjust of the Weight: (It is important to do the setting of the zero before doing this operation)

- a) Situate in the option of menu **[PESO]**
- b) Introduce **inside the cabin a well-known** weight & press **→**
Note: It is recommended at least as minimum **50%** of the complete load.
- c) Put the value of the weight placed in the cabin using the keys **←** **→**
- d) To save the value press the key **MENU** **2 times** (The unit will start to **count-down** and the value will be saved). Then the display will present the next parameter **[CELL]**

Note: If you haven't press the **MENU** for the 2nd time, the operation will not be stored, and the display presents again the parameter **[PESO]**

[CLR] Key to protect the parameters for a possible modification. Normally the unit comes out from the factory with the key of **0000**, that allows a free access to modify the parameters.
- In the case of putting another key different from **0000**, the access to modify the parameters is protected (it is highly recommended to remember your key)
- If the unit is protected with a key. And once entered in the menu the display **[CLR]** presents intermittently to request us the keycode. It is necessary to introduce the key at this time, if we want to modify some parameter.
- To introduce the key, while **[CLR]** is in intermittent, press the key **→** and a number will appear that it is necessary to substitute for the correct key.
Note: If you don't remind the key that you put on, write down the number that appears and **call the supplier**, it will indicate you the right key.

Alarms

The alarms are the load levels in which that change the state of the relay. To adjust them it is **not necessary any weight**, just program them on the key.

- [ALC]** Value of the load indicating that the elevators is complete. When the content of the elevator overcome this value, the state of the relay change to indicate the complete load, and the cabin display **MB-D** will light on up to the head of the dummy.
- [ALS]** Value of the load indicating that the elevator is in overload. When the content of the elevator overcome this value, the state of the relay change to overload. And the cabin display **MB-D** will indicate that the elevator is in overload by activating the buzzer or by optical warning.

Presentation of Errors.

- [Err1]** Load cell not well connected, damaged load cell or cut cable
- Revise the connection of the load cell.
- [Err2]** Negative Overflow.
- The load cell is working in a contrary sense or it is not well connected.
- [Err3]** Positive Overflow. (The load cell is supporting a superior weight than the nominal value.)
- It is necessary to put a load cell that has a superior nominal value.
- [Err4]** Polarity Error. (This error is detected when the unit adjusts the weight with the polarity of the load cell changed.)
- Revise the connection of the load cell.
- Repeat the setting of the zero and the adjust of weight.

QUICK PROGRAMMING GUIDE

1) Install the sensor and connect it to the unit control.

To connect properly the sensor to the unit control, please see section N° 1 (Installation)

This section is to know quickly the keys of this unit.

- a) To find the parameter that is wanted to change press successively **MENU** and to accede to the parameter press **→**
- b) Modify using these keys **←** **→**
- c) To save the data press 2 times **MENU**

2) Before to start to calibrate the unit control, please be advised to do the following:

- a) Down the cabin to the lower plant of the building. (or in the half of the itinerary)
- b) Bounce inside the cabin to avoid possible hooks on the guide rail.

3) Most important parameters to calibrate step by step:

- 1°. **Set the Zero** of the unit with the empty elevators:
 - Situate in the parameter **[CEQ]**
 - Press **→** **MENU** and will start to count-down.
- 2°. **Adjust of the Weight (Peso):**
 - Put a well known weight inside the cabin (at least **50%** of the complete load)
 - Introduce in the parameter **[PESO]** the value of the load that has been placed in the cabin using these keys **←** **→** then to save it press **MENU** 2 times and the unit will start to count-down.
- 3°. Put in **[ALC]** the value of the load, starting from which is required to activate the alarm of **complete load**. (Example: 100% of the nominal load)
- 4°. Put in **[ALS]** the value of the load, starting from which is required to activate the alarm of **overload**. (Example: 110% of the nominal load)